

### WINDSORONE GREEK REVIVAL




	BOARD	1x2 S4SSE		WINDOW STO	ol WOWS001
	CROWN	WOCM004		APRON	WOCS007
		1x2 S4SSE	⊾	COVE	WOCV001
	CASING	WOCS007		► BASE	WOBM002
		G WOBB002			

#### WINDSORONE SCALED UP GREEK REVIVAL (CSOO8)




		STOP MOLDING		,	APRON	WOCS008
	$\sim$	CROWN	WOCM004	L	COVE	WOCV001
		BOARD	1x2 S4SSE		BASE	1x6 S4SSE
		CASING	WOCS008			PLINTH
	•	BAND MOLDING	WOBB002			6-3/4" length) from 1-1/16"x
		WINDOW STOOI	WOWS001	7-1/4" to 1-1	/16"x6-3/4" (5	ö" length)

#### WINDSORONE SCALED UP GREEK REVIVAL (CS009)




		WOST004		WINDOW STOOL	WOWS001
	CROWN	WOCM004		APRON	WOCS009
	PICTURE MOLD	WOPM004	L .	COVE	WOCV001
	BOARD			BASE	1x8 S4SSE
	CASING	WOCS009	-	CUSTOM PL	INTH
	► BAND MOLDING	WOBB002	1-1/16"x8-1/4"	1x2 S4SSE (8-1/4 trimmed from 1-1 (6" length)	

## WINDSORONE BEADED CAPPED WITH GREEK





# WINDSORONE BULLNOSE WITH GREEK




		1x2 S4SSE			WOCS008
$\sim$	CROWN	WOCM004	•	BAND MOLDING	WOBB002
-	САР	WOWC003			1x6 S4SSE

#### WINDSORONE GRAND FRIEZE & CAP

Ref. no. WOGRK005

Note, this installation requires advanced carpentry skills.



Dec 2021 | WindsorONE.com | 888.229.7900 | AskTheBoys@WindsorONE.com

CASING

STOP MOLDING WOST001

WINDOW STOOL WOWS001

WOBM002

CUSTOM PLINTH 1x6 S4SSE (8-1/4" length)


would work for the plinth block.)

with corner trimmed, backed with same size S4S. (Without base shoe, 5/4x6 piece


#### WINDSORONE CROSSETTED W/ GREEK PROFILES

Ref. no. WOGRK004

Note, this installation requires advanced carpentry skills.



1x3 S4SSE (8-1/2"length) with bevel & 5/4x10 S4SSE trimmed from 1-1/16"x 9-1/4" to 1-1/16"x8-1/2" (6" length)



BAND MOLDING WOBB002 • WINDOW STOOL WOWS001


WOCS009\*

CASING

## WINDSORONE SPLAYED, TEMPLE STYLE

Ref. no. WOGRK007(v1),

Note, this installation requires advanced carpentry skills.




		STOP MOLDING	WOST004		WINDOW STOOL	WOWS001
	$\smile$	CROWN	WOCM004		APRON	1x5 S4SSE
יי ורוך	-	PICTURE MOLD	WOPM004	L	COVE	WOCV001
		BOARD	1x2 S4SSE			5/4x8 S4SSE
			1x8 S4SSE			5/4x8 S4SSE
	•	BAND MOLDING	WOBB002		from 5/4x8 and bac	

#### WINDSORONE SPLAYED GREEK MANTEL

Ref. no. WOGRKMT02

Note, this installation requires advanced carpentry skills and complements Splayed Greek Casing #WOGRK007




	BOARD	1x5 S4SSE	DOUBLE BEADED	WOCS010	
	HEADER CAP	WOHC001	BOARD	1x2 S4SSE	
	BOARD	5/4x12 S4SSE	VERTICAL CASING 5/4x8 S4SS		
	BOARD	1x3 S4SSE	&PLINTH Block has added depth with		
Þ	BACK BAND	WOBB002	casing pieces extending	g behind it.	

#### ALSO SEE SEE 3-DIMENSIONAL IMAGES FOR THIS DESIGN.

#### WINDSORONE GREEK MANTEL 3

Ref. no. WOGRKMT03

Note, this installation requires advanced carpentry skills



<b></b>	BOARD	5/4x5 S4SSE	-	STOP MOLDING	WOST001
	BOARD	5/4x6 S4SSE	₽	WAINSCOT CAP	WOWC003
	BOARD	1x12 S4SSE		BASE & CASING	
		1.6			

\*Top mantel piece can also be trimmed from 5/4x6 S4SSE leftover piece

#### ALSO SEE SEE 3-DIMENSIONAL IMAGES FOR THIS DESIGN.

Mar 2022 | WindsorONE.com | 888.229.7900 | AskTheBoys@WindsorONE.com